

Event report / measures

eng

Error message in display	Cause	Correction / measures
0 Probe defect	Conductivity probe defect or contaminated	Clean conductivity probe (hole)
1 Dispenser defect	Compact and/or Fluid and/or machine defect	Integral Compact NEW System start new
2 Water supply dispenser interrupted	No water at dosing device Compact	Check water supply Compact (Aquastopp)
3 Water supply machine interrupted	No water in machine	Check water supply in machine
4 Overflow	Rinse funnel and/or chemical hose blocked Compact	Clean rinse funnel Compact and/or chemical hose
5 Washing time	Washing time too short	Select longer washing program on machine
6 Cartridge missing	No cartridge inserted (Compact and/or Fluid)	Insert Compact or Fluid cartridge
7 Cartridge empty	Cartridge empty Compact and/or Fluid	Replace Compact or Fluid cartridge
8 Wrong product	Wrong product inserted Compact and/or Fluid	Insert correct product Compact or Fluid
9 Change washing water	Washing water severely contaminated	Change washing water
10 Water conditioning defect	Worn desalination or osmosis system	Repair desalination or osmosis
11 Excessive tank temperature	Tank water temperature too high	Check tank heating
12 Tank temperature too low	Water temperature in tank too low	Check tank heating
13 Boiler temperature too high	Water temperature in boiler too high	Check boiler heater
14 Boiler temperature too low	Water temperature in boiler too low	Check boiler heater