Fehlercodes

Anzeige	Nr.	Fehler/Service	Ursache / Behebung
FXXX	**F100**	**Fehler Pumpe** Pumpe dreht sich bei Abgabe nicht	Pumpenkopf überprüfen, eventuell Pumpenkopf tauschen
FXXX	**F200**	**Fehler Wasser** Kein Wasserdurchfluss bei Abgabe	Wasserversorgung prüfen, Wasserversorgung aufdrehen Aquastopp prüfen
	F201	min. Wasserdurchfluss	Wasserdurchfluss zu gering
	F202	max. Wasserdurchfluss	Wasserdurchfluss zu hoch Mittels Druckregler drosseln
FXXX	**F300**	**Fehler Nachfüllung** Flasche nicht richtig eingesetzt	Nachfüllung entriegeln, Flasche nach unten drücken und verriegeln
	F301	**Fehler RFID** Daten Version	Falsches Produkt
	F302	**Fehler Markt Codierung**	Falsche Patrone, falsche Markt Codierung
	F303	**Fehler Produkt Typ**	Falsches Produkt eingelegt Spender zurücksetzen
	F304	**Fehler RFID Kommunikation**	Patrone aus dem Spender entnehmen und wieder einsetzen bzw. eine neue einsetzen
	F305	**Falsches Produkt**	Nachfüllung überprüfen
	F306	**Fehler Dosiermodus**	Dosiermodus nicht unterstützt
SXXX	**S100**	**Service Pumpe** Pumpenlebensdauer erreicht	Pumpe tauschen (siehe „Pumpenwechsel“ bei Anleitung)
SXXX	**S300**	**Service Nachfüllung** Nachfüllung leer	Entriegeln, leere Nachfüllung entnehmen neue Nachfüllung einsetzen
	S301	**Service Nachfüllung** maximale Menge aus Nachfüllung entnommen,	

Error codes

Display	*No.*	*Error/Service*	*Remedy*
FXXX	***F100***	**Error Pump** *Pump does not turn during dispensing*	*Check pump head, replace pump head as needed*
FXXX	***F200***	**Error Water** *No water flow during dispensing*	*Check water supply,* *Open water supply*
	F201	*Min. water flow rate*	*Water flow rate too low*
	F202	*Max. water flow rate*	*Water flow rate too high* *Reduce water flow through pressure regulator*
FXXX	***F300***	***Error Refill*** *Bottle inserted incorrectly*	*Unlock refill, push bottle down and lock*
	F301	***Error RFID*** *Data Version*	*Wrong product*
	F302	***Error distributor protection***	*Wrong product,* *wrong distributor protection*
	F303	***Error Product type***	*Wrong cartridge,* *Wrong Market encoding*
	F304	***Error RFID Communication***	
	F305	***Wrong product***	*Check refill*
	F306	***Error dosingmode***	*Dosingmode not supported*
SXXX	***S100***	***Service Pump*** *Pump life cycle reached*	*Exchange PUMP integral 2GO (See “Pump exchange” with instructions)*
SXXX	***S300***	***Service Refill*** *Refill empty*	*Unlock, remove the empty refill and insert new refill*
	S301	***Service Refill*** *Maximum quantity removed from refill, Refill empty*	