

# integral 4PLUS

**sr**

**en**




## Dobro došli!

Sa integral 4PLUS dozatorom odlučili ste se za precizan, automatski dozirni uređaj za profesionalne mašine za pranje suđa. Sa integral 4PLUS-om možete dozirati tečne visokokoncentrisane deterdžente i sredstva za sjaj. Time pokrivate sve potrebe u kuhinji.

U ovom uputstvu za upotrebu objašnjena je montaža i upotreba uređaja. Uz to možete naći na [www.hagleitner.com](http://www.hagleitner.com) film za korisnike za montažu, prvo korišćenje i primenu Vašeg novog sistema dozatora.

Zahvaljujemo se na tome, što ste se odlučili za ovaj HAGLEITNER proizvod. Kod pitanja, problema i želja radujemo se Vašoj adresi i telefonskom broju za uspostavu kontakta!

U multiFILL patroni: visoko koncentrisan deterdžent i sredstvo za sjaj  
Kompaktan assortiman za profesionalno pranje suđa



### Deterdžent

**ecosol POWER** Br. art. 4220101119

**ecosol POWER ALU** Br. art. 4220101319

**ecosol POWER OSMO GL**  
Br. art. 4220101219

### Sredstvo za sušenje do sjaja

**ecosol BRITE N** Br. art. 4220200319

**ecosol BRITE S** Br. art. 4220200419



Za uputstvo za upotrebu na Vašem jeziku molimo  
skenirati ovaj QR-Code:  
<http://www.hagleitner.com/en/downloads/>


## Welcome!

With your selection of the integral 4PLUS dispenser, you have chosen a precise and fully automated dosing unit for industrial, commercial dishwashing machines. Integral 4PLUS dispenser is a dosing device for liquid, concentrated dishwashing detergent and rinse-aid. Specially developed to cover the requirements of commercial dishwashing.

These operating instructions explain the installation and operation of the unit. For further support, go to [www.hagleitner.com](http://www.hagleitner.com) and view a user video about the installation, initial start-up and use of your new dispensing system.

Thank you for choosing this HAGLEITNER product. We look forward to receiving your address and telephone number to make contact in the event of questions, problems or suggestions!

In the multiFILL cartridge: concentrated detergent and rinse-aid  
A compact assortment for commercial dishwashing



### Cleaner

<b>ecosol POWER</b>	Art.-No. 4220101119
<b>ecosol POWER ALU</b>	Art.-No. 4220101319
<b>ecosol POWER OSMO GL</b>	Art.-No. 4220101219

### Rinse-aid

<b>ecosol BRITE N</b>	Art.-No. 4220200319
<b>ecosol BRITE S</b>	Art.-No. 4220200419



Please scan this QR code for instructions for use in your language:  
<http://www.hagleitner.com/en/downloads/>

## Sadržaj

Šta Vam treba .....	6
Sadržaj isporuke .....	7
integral 4PLUS dozator .....	7
integral 4PLUS FLOWMETER .....	8
integral 4PLUS PUMP POWER / BRITE .....	8
integral 4START POWER / BRITE .....	9
integral 4PLUS powerPACK ex .....	9
Opcija: integral 4WALL .....	10
Opcija: integral 4PLUS DISPLAY .....	10
Lista alata .....	10
Mogućnosti montaže .....	11
Monzača ispod stola/na zidu .....	11
Ubaciti pumpu .....	13
Ubaciti label .....	18
Montaža pojedinačnog dozatora .....	19
Montaža pojedinačnog dozatora ispod stola .....	19
Montaža pojedinačnog dozatora na zidu .....	22
Montaža u nizu .....	24
Montaža u nizu ispod stola .....	24
Montaža u nizu na zidu .....	28
Montaža integral 4PLUS FLOWMETER .....	32
Polaganja creva & kablova pojedinačnog dozatora .....	34
Polaganja creva & kablova .....	34
Postaviti delove sa strane .....	36
Postaviti dozator .....	37
L-deo spojiti .....	39
Kablove povezati .....	41
Polaganja creva & kablova montaža u nizu .....	43
Polaganja creva & kablova .....	43-44
Postaviti delove sa strane .....	45
Postaviti dozator .....	46
L-delove spojiti .....	48
Kablove povezati .....	51
Montaža priključka za deterdžent .....	52
Montaža ulaza u rezervoar .....	52
Montaža priključka za sredstvo za sjaj .....	54
Montaža povratni ventil .....	54
Priključak struje .....	55
App: Aktiviranje dozatora .....	56
Noseći delovi .....	56
Upotreba .....	57
Zamena patrona .....	57
Piktogrami .....	58



## Content

<b>What you need .....</b>	<b>6</b>
<b>Scope of delivery .....</b>	<b>7</b>
integral 4PLUS dispenser .....	7
integral 4PLUS FLOWMETER .....	8
integral 4PLUS PUMP POWER / BRITE .....	8
integral 4START POWER / BRITE .....	9
integral 4PLUS powerPACK ex .....	9
Option: integral 4WALL .....	10
Option: integral 4PLUS DISPLAY .....	10
Tool list .....	10
<b>Mounting options .....</b>	<b>11</b>
Undertable/wall mounting .....	11
<b>Insert pump .....</b>	<b>13</b>
Insert label .....	18
<b>Installation individual dispenser .....</b>	<b>19</b>
Under table installation individual dispenser .....	19
Wall installation individual dispenser .....	22
<b>Row installation .....</b>	<b>24</b>
Row installation under table .....	24
Row installation wall .....	28
<b>Installation integral 4PLUS FLOWMETER .....</b>	<b>32</b>
<b>Hose and cable installation individual dispenser.....</b>	<b>34</b>
Hose/cable installation .....	34
Side part mounting .....	36
Dispenser mounting .....	37
Connecting L-part .....	39
Connecting cable .....	41
<b>Hose and cable installation row installation .....</b>	<b>43</b>
Hose/cable installation .....	43-44
Side part mounting .....	45
Dispenser mounting .....	46
Connecting L-parts .....	48
Connecting cable .....	51
<b>Installation cleaner connection .....</b>	<b>52</b>
Installation tank inlet .....	52
<b>Installation rinse-aid connection .....</b>	<b>54</b>
Installation check valve .....	54
<b>Power connection .....</b>	<b>55</b>
<b>App: activation dispenser .....</b>	<b>56</b>
<b>Wearing parts .....</b>	<b>56</b>
<b>Operation .....</b>	<b>57</b>
Cartridge exchange .....	57
<b>Pictograms .....</b>	<b>58</b>



**Skinite HAGLEITNER APP.**  
*Download the HAGLEITNER App.*



**Tehnički podaci / Technical specifications:**

Težina / Weight:

Zid/wall 3,7 kg,  
Pod/floor 3,37 kg  
Zid/wall 34,5, pod/floor  
27,5 (V) x 17,8 (Š) x 22,2 cm (D)

Mere / Dimensions:

min. 1 l/min., max. 20 l/min

Protok vode / Water flow rate:

3/4 Zoll/inch

Priključak vode / Water connection:

max. 8 bar @ 20° C

Pritisak / Pressure:

max. 5 bar @ 40° C

Temperatura vode / Water temperature:

5–60° C

Temperatura okoline / Ambient temperature:

5–30° C

Napon snabdevanja / Supply voltage:

24 V-DC / 1,5 A max.

Mreža / System voltage:

230 V (EU); 110 V (USA)

Montaža u nizu / Row installation:

max. 3 uređaja / devices







Vrsta zaštite / Protection class:

IP21

### Integral 4PLUS dozator / integral 4PLUS dispenser

- ① integral 4PLUS - dozator
- ② Deo sa strane levo
- ③ Deo sa strane desno
- ④ Montažna ploča gore
- ⑤ Montažna ploča dole
- ⑥ Uputstvo za upotrebu
- ⑦ Set za montažu
- ⑧ Ploča za spajanje




- ① *integral 4PLUS - Dispenser*
- ② *side part left*
- ③ *side part right*
- ④ *mounting plate top*
- ⑤ *mounting plate bottom*
- ⑥ *operating instructions*
- ⑦ *mounting kit*
- ⑧ *connecting plate*




## Integral 4PLUS FLOW METER / integral 4 PLUS FLOW METER

- ① Brojilo vode
- ② Buskabal 3 m
- ③ Zaptivka


- ① flow meter
- ② bus cable 3 m
- ③ seal



## integral 4PLUS PUMP POWER / integral 4PLUS PUMP POWER





## integral 4PLUS PUMP BRITE / integral 4PLUS PUMP BRITE



## integral 4PLUS powerPACK ex / integral 4PLUS powerPACK ex


- ① Mrežni deo sa priključnim kablom 2 m
- ② Kabal uređaja 1,8 m

- ① power supply unit with cable 2 m
- ② plug 1,8 m



## integral 4START POWER / integral 4START POWER


- ① L-komad
- ② Ulaz u tank
- ① L-part
- ② tank inlet



## integral 4START POWER PIPE / integral 4START POWER PIPE

- ① Crevo za deterdžent 6 m - Ø 8 mm
- ② Vezice za kabal
- ③ Samolepivi držač
- ④ Krpa za čišćenje


- ① hose for detergent 6 m Ø 8 mm
- ② cable ties
- ③ adhesive mounts
- ④ cleaning cloth



## integral 4START BRITE / integral 4START BRITE

- ① L-komad
- ② Povratni ventil


- ① L-part
- ② check valve



## integral 4START BRITE PIPE / integral 4START BRITE PIPE

- ① Crevo za sredstvo za sjaj 6 m - Ø 6 mm
- ② Vezice za kabal
- ③ Samolepivi držač
- ④ Krpa za čišćenje



- ① hose for rinse-aid 6m - Ø 6 mm
- ② cable ties
- ③ adhesive mounts
- ④ cleaning cloth



## Opcija: integral 4WALL / Option: integral 4WALL

- ① 3-delni set za zidnu montažu
- ② 2 vijka, 2 tiple,  
2 podložne pločice
- ③ Vijak kratki



- ① 3 parts module for wall
- ② 2 screw, 2 dowel, 2 washer
- ③ screw short




## Opcija: integral 4PLUS DISPLAY / Option: integral 4PLUS DISPLAY

- ① integral 4PLUS DISPLAY
- ② 2 vijka, 2 tiple,  
2 podložne pločice
- ③ Lepljiva traka
- ④ Krpa za čišćenje

- ① integral 4PLUS DISPLAY
- ② 2 screw, 2 dowel, 2 washer
- ③ adhesive strip
- ④ cleaning cloth




## Lista alata / tool list




## Mogućnosti montaže / mounting options

### Monzaža ispod stola / undertable mounting



### Zidna montaža / wall mounting



DIN VDE 100  
Zone 3

DIN VDE 100  
Zone 2



230V



24V



max. 3 m

max. 3 m



3/4 Zoll



6 m




max. 6 m




## Ubaciti pumpu / insert pump

### Ubaciti pumpu / insert pump


#### 1. Skenirati dozator / scan dispenser




#### 2. Skenirati pumpu / scan pump




**3.** Skenirati brojilo za vodu / scan flow meter






**4.**




**5.**




6.







7.



8.




9.





PRESS

①





gore /  
upside




PUSH  
UP

②



③




Uverite se, da je posuda za hemiju  
sela kako treba i da stoji čvrsto!



*Make sure that the chemistry coupling is correctly locked and fixed.*

**Postaviti label / insert label**

1.



2.




**3. Pratite APP / follow the APP**


## Montaža pojedinačnog dozatora / Installation individual dispenser

Montaža pojedinačnog dozatora ispod stola / under table installation individual dispenser


1.




2.




**3.**



**4.**





**4 x**



**5.**




4 x



**6.**





4 x



## Montaža pojedinačnog dozatora na zidu / wall installation individual dispenser



1.

Stiker /  
template



2.

4 x





①




②

③


3.




## Opcija




4. 2 x




5. 2 x



6.




7. 2 x




## Montaža u nizu / Row installation

### Montaža u nizu ispod stola / row installation under table


1.




2.




**3.**




**4.**



**5.**





**2 x 4**





**6.**




**8 x**






## Montaža u nizu na zidu / row installation wall


1.






2.



3.






## Opcija



4. 2 x 2 x


2 x

5. 1 2 x




CLICK))

7. 2 x



8.




9.




2 x




2 x



10.  2 x





11.



 CLICK))  
↑


12.

 2 x




max.  
3 dozatora /  
*dispenser*


## Montža integral 4PLUS FLOWMETER / installation integral 4PLUS FLOWMETER




1.




2.



3.




4.




Priklučak vode: 3 za mašinu za suđe/4 Zoll / water supply dish washer

5.




6.





## Polaganja creva & kablova pojedinačnog dozatora / hose and cable installation individual dispenser



### Polaganja creva / hose installation

1.




### Polaganja kablova / cable installation








## Postaviti delove sa strane / side part mounting



levo  
left




desno  
right




## Postaviti dozator / dispenser mounting



1.




2.



3.




4.




## L-deo spojiti / connecting L-part



1.




2.



3.




4.







Za lakše dodavanje: navlažite crevo /  
For easy mounting: moisten the hose



5.



## Kablove povezati / connecting cable


1.






## Polaganja creva & kablova montaža u nizu / hose and cable installation row installation





### Polaganja creva / hose installation




### Opcija



## Polaganja kablova / cable installation




## Postaviti delove sa strane / side part mounting



levo  
left




desno  
right




## Postaviti dozator / dispenser mounting


1.




2.



3.




4.




## L-delove spojiti / connecting L-parts



1.




2.



Koristite ovde L-deo  
„integral 4START POWER“  
Use here the L-Part  
„integral 4START POWER“




3.



Za lakše dodavanje: navlažite crevo /  
For easy mounting: moisten the hose

4.





5.






Koristite ovde L-deo  
„integral 4START BRITE“  
Use here the L-part  
„integral 4START BRITE“

Ponovite korake 1-4 kod postavljanja  
L-komada u dozatoru za sredstvo za sjaj.  
Repeat steps 1-4 to fix the L-part in the  
rinse-aid dispenser.






## Kablove povezati / connecting cable

1.




2.




### Montaža ulaza u rezervoar / installation tank inlet

1.





2.

Creva uvući u mašinu, koristite za ovo predviđene ulaze u mašinu (zadnja strana).  
Use the machine inputs for hoses to put the hoses into the machine.




#### Pozicija ulaz u tank



1. U tanku za pranje mašine
  2. Ispod korpe
  3. Iznad nivoa vode
  4. Ne direktno iznad motora ili platina
  5. Lak pristup i vidljiv (otvorene mašine)
- Position tank inlet:
1. In the washing tank of the machine
  2. Below the basket guide rail
  3. Above water level
  4. Not directly above motors or boards
  5. Easy to access and visible (open machine)



**3.**





**4.**






## Montaža priključka za sredstvo za sjaj / installation rinse-aid connection

### Montaža povratni ventil / installation check valve

1.



2.




Kablove i creva rasteretiti  
Make sure that all cables and hoses are relieved of strain.

## Priklučak struje / power connection


1.




100~240VAC  
50/60Hz




2.



3.




4.




Kablove i creva rasteretiti  
Make sure that all cables  
and hoses are relieved of  
strain.

## App: Aktiviranje dozatora / App: activation dispenser

1.



2. Proveriti nakon puštanja u rad It. App /  
Check after installation according to the app




## Noseći delovi / wearing parts

integral 4PLUS FLOW METER  
integral 4PLUS PUMP POWER  
integral 4PLUS PUMP BRITE

Intervali za održavanje potrošnih delova automatski se prikazuju proaktivno u aplikaciji. / Service intervals and exchange of wear parts are announced in the app proactive.

### Zamena patrona / cartridge exchange



## Piktogrami / pictograms

### integral 4PLUS Spender / integral 4PLUS dispenser

Piktogram pictogram		Boja colour	Signal signal
	<b>Spremno za upotrebu / Ready to use</b>	zeleno green	Dozator je spreman za upotrebu <i>dispenser is ready to use</i>
		oranž orange	Dozator radi, postoji problem - detalji u App <i>dispenser is working, maintenance required – details in APP</i>
		crveno red	Dozator ne radi (Dozator je otvoren, patrona i rezervni tan su prazni) <i>dispenser is not working (dispenser is open, cartridge and reserve tank empty)</i>
		bez boje no colour	Dozator nema struju <i>no power supply available</i>
	<b>Patrona / Cartridge</b>	oranž orange	Patrona je prazna - dozator radi u rezervnom modusu <i>cartridge is empty, dispenser on reserve tank mode</i>
		crveno red	Patrona je prazna, pogrešan proizvod je u dozatoru, RFID se ne može očitati, dozator je otvoren, nema patrona u dozatoru <i>cartridge is empty, wrong product, RFID not available, dispenser is open, no cartridge in dispenser</i>
	<b>Bluetooth</b>	plavo blue	Dozator je povezan sa App <i>dispenser and App are connected</i>

## integral 4PLUS Display / integral 4PLUS display

Piktogram pictogram		Boja colour	Signal signal
	<b>Spremno za upotrebu / Ready to use</b>	zeleno green	Dozator je spreman za upotrebu <i>dispenser is ready to use</i>
		oranž orange	Dozator radi, postoji problem - detalji u App <i>dispenser is working, maintenance required – details in APP</i>
		crveno red	Dozator ne radi (Dozator je otvoren, patrona i rezervni tan su prazni) <i>dispenser is not working (dispenser is open, cartridge and reserve tank empty)</i>
		bez boje no colour	Baterija statusne trake je prazna <i>battery is empty</i>
 	<b>Patrona / Cartridge</b>	oranž orange	Patrona je prazna - dozator radi u rezervnom modusu <i>cartridge is empty, dispenser on reserve tank mode</i>
		crveno red	Patrona je prazna, pogrešan proizvod je u dozatoru, RFID se ne može očitati, dozator je otvoren, nema patrone u dozatoru <i>cartridge is empty, wrong product, RFID not available, dispenser is open, no cartridge in dispenser</i>
	<b>baterija / battery</b>	Rot red	baterija se prazni <i>Battery drain</i>

# EC-DECLARATION of CONFORMITY

The distributor: Company  
Hagleitner Hygiene International GmbH  
Lunastraße 5  
5700 Zell am See

declares under his sole responsibility for the following system:

## Integral 4PLUS

Type: Dosing System	Mach. Nr.: P0343
---------------------	------------------

that all the relevant provisions of following *European Directives* are fulfilled:

2006/42/EC	Machinery Directive
2014/53/EU	Radio Equipment Directive
2014/35/EU	Low Voltage Directive
2014/30/EU	Electromagnetic Compatibility
2011/65/EU	Restriction of certain hazardous substances in electronic equipment

and that the system corresponds with the relevant sections of following standards and/or other normative documents:

EN ISO 12100	Safety of machinery
EN 61000-6-3	Electromagnetic compatibility (EMC) – Emission
EN 61000-6-2	Electromagnetic compatibility (EMC) - Immunity for industrial environments
EN 300330	Spurious emissions and Spektrummask

Zell am See, 16.12.2019



Hans Georg Hagleitner  
Chief Executive Officer  
Hagleitner Hygiene International GmbH

Art.-Nr. 20702070001  
10-2022 / DSSP092-06